

Project: [Open Microscopy Environment](#)
Authors: [David Sloan](#), [Xinyi Jiang](#), [Jean-Marie Burel](#)
Version: 3.0-Beta
Date: 2007-06-11

OMERO clients User Guide



Table Of Contents

1. Introduction.....	1
2. Getting started with OMERO	2
2.1. Installing OMERO.importer and OMERO.insight	3
2.2. Logging in.....	4
2.3. Importing images	5
2.4. Viewing images	8
2.4.1. Viewing a single image	9
2.4.1.1. Viewing z-sections or timepoints.....	11
2.4.1.2. Adjusting channels.....	12
2.4.1.3. Additional viewing options	13
2.4.2. Viewing a selection of images: the Hierarchy Viewer.....	14
2.5. Saving images.....	16
3. Advanced OMERO.....	17
3.1. Getting to know the Data Manager	19
3.2. Viewing and editing user account details	21
3.3. Managing projects and datasets	22
3.3.1. Creating projects and datasets.....	23
3.3.2. Renaming projects or datasets.....	27
3.3.3. Removing projects or datasets.....	28
3.3.4. Expanding a project to see constituent datasets.....	29
3.3.5. Expanding a dataset to see constituent images	30
3.3.6. The Projects, Categories and Images tabs	31
3.4. Viewing other people's images	32
3.5. Additional information about projects, datasets and images	34
3.6. Annotations	35
3.6.1. Viewing annotations	36

3.6.2. Annotating a single image or dataset	37
3.6.3. Annotating multiple images or datasets	38
3.7. Categorising images.....	40
3.7.1. Creating category groups.....	41
3.7.2. Creating categories.....	42
3.7.3. Removing categories and category groups	43
3.7.4. Categorising images	44
3.7.4.1. Categorising a single image	45
3.7.4.2. Categorising multiple images.....	46
3.7.4.3. Viewing images in a category.....	47
3.7.4.4. Removing an image from a category.....	48
3.8. Sorting and finding images.....	49
3.8.1. Sorting images	50
3.8.2. Retrieving selected images	52
3.8.3. Finding images with Find in Tree	54
3.9. Viewing images	56
3.9.1. Viewing a specific Channel	58
3.9.2. Additional viewing options.....	59
3.9.2.1. Colour and greyscale viewing	60
3.9.2.2. Movie viewing across channels	61
3.9.2.3. Channel configuration.....	62
3.9.2.4. Image information.....	64
3.9.2.5. Annotation View.....	65
3.9.3. Magnification	66
3.9.3.1. Magnifying the whole image.....	67
3.9.3.2. Magnifying an area of the image	68
3.9.3.3. Scale bar.....	70
3.9.4. Viewing z-sections and timepoints.....	71

3.9.4.1. Automated viewing of z-sections and timepoints	72
3.9.4.2. Selecting z-section and timepoints.....	73
3.9.4.3. Additional Movie Player options for z-section and timepoint viewing.....	74
3.9.5. Image Rendering options	76
3.10. The Hierarchy Viewer: viewing multiple images.....	80
3.10.1. Viewing an image from the Hierarchy Viewer.....	82
3.10.2. Using the Hierarchy Viewer	83
3.10.2.1. Adjusting thumbnail display.....	84
3.10.2.2. Display Tree View of images	87
3.10.2.3. Sorting images.....	88
3.10.2.4. Managing images in the Hierarchy Viewer.....	89
3.10.2.5. Additional image information: the Working Area	90
3.11. Managing windows in OMERO.insight	92
3.12. Closing OMERO.insight	93
4. Feedback reporting	94
4.1. Help Information	95
4.2. Feedback Facility	96
5. Background information.....	97
5.1. What is OMERO?	98
5.2. The OMERO Environment: client and server	99
5.3. 5-Dimensional images.....	100
5.4. The OMERO Data Model and Hierarchies.....	101

1. Introduction

Welcome to OMERO

This document provides a comprehensive guide to the Beta version of the OMERO.importer and OMERO.insight. These applications together allow you to import your microscopy images into the OMERO system, and manage, manipulate and view them.

The software was released for general use in June 2007.

This guide includes the following sections:

- [Section 2 - Getting started with OMERO](#). Installing the software, and a brief guide to importing images using OMERO.importer and performing basic image management, viewing and manipulation tasks using OMERO.insight.
- [Section 3 - Advanced OMERO](#). More details on using OMERO.insight.
- [Section 4 - Help and feedback](#). How you can provide the development team with feedback to influence future development.
- [Section 5 - Background information](#). The concepts and models behind the OMERO suite of software.

Enjoy using the software!

The OMERO development team, University of Dundee, UK.

2. Getting started with OMERO

This section provides you with the essential information you need to perform key tasks using OMERO:

- Installing the software;
- Logging in;
- Importing images;
- Viewing single/multiple image(s);
- Annotating images;
- Saving images.

More advanced tasks are described in .

- 2.1. Installing OMERO.importer and OMERO.insight
- 2.2. Logging in
- 2.3. Importing images
- 2.4. Viewing images
 - 2.4.1. Viewing a single image
 - 2.4.1.1. Viewing z-sections or timepoints
 - 2.4.1.2. Adjusting channels
 - 2.4.1.3. Additional viewing options
 - 2.4.2. Viewing a selection of images: the Hierarchy Viewer
- 2.5. Saving images

2.1. Installing OMERO.importer and OMERO.insight


Latest versions of OMERO.importer and OMERO.insight are available for download from:
<http://trac.openmicroscopy.org.uk/omero/wiki/MilestoneDownloads>

Once you have downloaded the OMERO.importer and OMERO.insight installer packages, double-click the packages to start the install process.

2.2. Logging in

The log-in procedure is the same for OMERO.importer and OMERO.insight.

When you start OMERO.importer, you will be asked to log in (See [Figure 2.2-1](#)). The administrator who set up OMERO can provide you with a user account and the address of the OMERO.server where your images will be stored.

You provide the address of the OMERO server by selecting the  button and entering the details in the form provided.




Figure 2.2-1 : Log in screens for OMERO.importer and OMERO.insight

Once logged in successfully, the appropriate OMERO application will open up.

2.3. Importing images

OMERO currently allows you to import the following file formats:

- Bio-Rad PIC (*.pic)
- Deltavision (*.dv, *.r3d, *.r3d_d3d)
- Digital Imaging and Communications in Medicine (*.dcm, *.dicom)
- Leica (*.lei, *.tif, *.tiff)
- Metamorph STK (*.stk)
- Tagged Image File Format (*.tif, *.tiff)
- Zeiss Laser-Scanning Microscopy (*.ism)

You can use OMERO.importer to select images from a storage disk and import them into the OMERO system.




Figure 2.3-1 : OMERO.importer in File Viewer mode





Figure 2.3-2 : import window, showing images destination and filename options

To import images into OMERO:

1. Log into OMERO.importer. The application will open a window similar to that shown in [Figure 2.3-1](#).
2. Use the **File Viewer** panel to browse and select one or more images you would like to import.
3. Add the selected images to the list of images for importing (referred to as the **Import Queue**) by selecting the plus button: 
4. The import window appears - see [Figure 2.3-2](#), prompting you to select a Project and Dataset - this will be the destination on the OMERO.server for the imported images. In this window you can:
 - a. Select an existing Project and Dataset from the menus shown, if you have previously created them in either OMERO.importer or OMERO.insight.
 - b. Or, for first-time OMERO users, use the Add button to create a new Project. You can then create a new Dataset in your new Project, or a new Dataset in an existing Project.
 - c. The bottom half of the import window (see [Figure 2.3-2](#)) also allows you to select a filename from one of three options:
 - i. the "short" file name e.g. "myImage.dv",
 - ii. the full path name e.g "c: important_work/stuff/myImage.dv",
 - iii. the short file name plus a number of leading directories, e.g. if you choose to add one directory to the directory "c:important_work/stuff/myImage.dv", your final imported image would be named "stuff/myImage.dv".

- d. You can also choose to import a copy of the image file in its original format.
5. You can continue to select more images to add to the Import Queue, by following steps 2-4 above.
6. Once you have finished selecting images, select the Import button at the bottom right hand corner of the window. The import process will now start. You can view the progress in the Status column of the Import Queue window. You may also add additional images to the import queue while an import is already running. This will only add the images to a new queue - when you are ready to import these new images, click the import button again to begin importing them.
7. When all selected images have status of "done", your images have been successfully imported, and you can then move to OMERO.insight to start working with your images.

OMERO.importer has two additional options to File Viewer mode:

- The Output Text mode: clicking on the **Output Text** tab shows you a brief list of the current import status as files are being imported.
- The Debug Text mode: clicking on the **Debug Text** tab shows you more technical information about the import status as files are being imported.

2.4. Viewing images

Once you have imported some images using OMERO.importer, open OMERO.insight to view them either individually or as a selection of thumbnails.

When you first log in to OMERO.insight, you will see the image filenames listed under the relevant Project and Dataset in OMERO.insight's **Data Manager** (see [Figure 2.4-1](#)).

See [Section 3.1](#) for a fuller description of the Data Manager.





Figure 2.4-1 : Data Manager Window, showing images stored in OMERO

- 2.4.1. Viewing a single image
 - 2.4.1.1. Viewing z-sections or timepoints
 - 2.4.1.2. Adjusting channels
 - 2.4.1.3. Additional viewing options
- 2.4.2. Viewing a selection of images: the Hierarchy Viewer

2.4.1. Viewing a single image

To view an image:

- Either double-click on the image filename,
- Or select the image filename, and then select the View Image button .

In either case the image will be displayed in a new window - the **Image Viewer** window. The Image Viewer allows you to view your image in three different ways:

- Standard Image View (see [Figure 2.4.1-1](#)).
- Annotation View: reduced size image with details of annotations shown (see [Figure 2.4.1-2](#)).
- Split View: showing each channel as a separate image (for multi-channel images), plus composite image, side-by-side (see [Figure 2.4.1-3](#)).

You can view more than one image at the same time -each will open in a separate **Image Viewer** window.




Figure 2.4.1-1 : Image Viewer, Standard View




Figure 2.4.1-2 : Image Viewer, Annotation View




Figure 2.4.1-3 : Image Viewer, Split View

2.4.1.1. Viewing z-sections or timepoints

2.4.1.2. Adjusting channels

2.4.1.3. Additional viewing options

2.4.1.1. Viewing z-sections or timepoints

For images with multiple z-sections or timepoints, OMERO allows you to easily view these manually or automatically.

To manually view composite z-sections or timepoints for an image in the **Image Viewer** window (all three views):

- Use the vertical Z slider to manually view individual z-sections.
- Use the horizontal T slider to manually view individual timepoints.

Or, open the **Controls** menu and select the **Movie** option to open the **Movie Player**. Here you can play all z-sections or timepoints in sequence, as a movie.

Alternatively, Holding down the mouse button and dragging the mouse vertically up or down the image moves through z-sections; dragging horizontally moves through timepoints. Dragging diagonally will simultaneously change z-sections and timepoints.

For more details on viewing z-sections and timepoints using the Movie Player, see [Section 3.9.4](#).

2.4.1.2. Adjusting channels

To adjust channels for multi-channel images, in the Image Viewer (Standard View or Split View):

- Use the colour buttons on the left-hand side of the image to turn on or off a colour channel.
- Switch between colour and greyscale representations of the image by going into the **Controls** menu, selecting **Models** , and choosing **Colour** or **Greyscale** .

For more details on adjusting channels, see [Section 3.9](#)

2.4.1.3. Additional viewing options

The Image Viewer provides a number of additional tools:

- Adjust the image properties using the Rendering Tool (see [Section 3.9.3.5](#)).
- Magnify an image or area of interest within the image (see [Section 3.9.3](#)).
- View in greyscale; or view additional information about the image (see [Section 3.9.2](#)).
- Configure the optional scale bar (see [Section 3.9.3.3](#)).

2.4.2. Viewing a selection of images: the Hierarchy Viewer

A selection of images for viewing can be made at different levels, based on how your data is organised in OMERO. You can:

- Select one or more projects - this selects all images in each dataset belonging to the selected project(s) groups.
- Select one or more datasets - this selects all images in the selected datasets.
- Select one or more images, by using the keyboard and/or mouse to select more than one image filename from the list shown in the left-hand pane.

NB


You can also select images according to the Category they belong to, which is another way of organising your data - you define your own category groups and categories, and then you can place your images into one or more categories. For more on categories, see [Section 3.7](#).

To view a selection of images:

1. In the Data Manager, select the first project, dataset, category group, category or image you wish to view by clicking once to highlight it.
2. Use the appropriate keys for your operating system to select subsequent projects, datasets, category groups, categories or images.

NB

You can only select multiple objects of the same level - for example you can select 5 images, but not one dataset plus 5 images. However, you can select individual datasets from different projects if desired.

3. Once you have your selection, select the Browse button . This brings up a Hierarchy Viewer window showing a series of thumbnails, one for each image in your selection (see [Figure 2.4.2-1](#)).




Figure 2.4.2-1 : Hierarchy Viewer, showing simple selection of images


The Hierarchy Viewer also provides:

- a range of tools for viewing individual thumbnails;
- options to rearrange the display of thumbnails;
- facilities to display and edit information relating to a particular thumbnail.

See [Section 3.10.2](#) for more details.

2.5. Saving images

You can save a copy of any image displayed in the Image Viewer, in a number of different image formats. This may be particularly useful for having a copy to include in a presentation or publication.

1. Open the **Controls** menu and select the **Save As** option. Or, select the  icon in the **Image Viewer**.
2. In the Save Image window you can:
 - a. Specify the name of the saved image file.
 - b. Select the destination of the saved image file (this can be set to be the default folder for future save operations).
 - c. Select the saved image file format from a choice of BMP, JPEG, TIFF or PNG.
 - d. Choose the type of image to save - in the Images menu, select from:
 - A simple image;
 - Image and split channels in grid form;
 - Image and split channels in a row;
 - Image and split channels in a row, in grey;
 - Lens image;
 - Lens image and split channels;
 - Lens image and split channels in grey.
3. You will see a preview of the image to be saved before you confirm the save action.

3. Advanced OMERO

This section provides more in-depth information on the tasks OMERO.insight supports.

- 3.1. [Getting to know the Data Manager](#)
- 3.2. [Viewing and editing user account details](#)
- 3.3. [Managing projects and datasets](#)
 - 3.3.1. [Creating projects and datasets](#)
 - 3.3.2. [Renaming projects or datasets](#)
 - 3.3.3. [Removing projects or datasets](#)
 - 3.3.4. [Expanding a project to see constituent datasets](#)
 - 3.3.5. [Expanding a dataset to see constituent images](#)
 - 3.3.6. [The Projects, Categories and Images tabs](#)
- 3.4. [Viewing other people's images](#)
- 3.5. [Additional information about projects, datasets and images](#)
- 3.6. [Annotations](#)
 - 3.6.1. [Viewing annotations](#)
 - 3.6.2. [Annotating a single image or dataset](#)
 - 3.6.3. [Annotating multiple images or datasets](#)
- 3.7. [Categorising images](#)
 - 3.7.1. [Creating category groups](#)
 - 3.7.2. [Creating categories](#)
 - 3.7.3. [Removing categories and category groups](#)
 - 3.7.4. [Categorising images](#)
 - 3.7.4.1. [Categorising a single image](#)
 - 3.7.4.2. [Categorising multiple images](#)
 - 3.7.4.3. [Viewing images in a category](#)
 - 3.7.4.4. [Removing an image from a category](#)
- 3.8. [Sorting and finding images](#)
 - 3.8.1. [Sorting images](#)
 - 3.8.2. [Retrieving selected images](#)
 - 3.8.3. [Finding images with Find in Tree](#)
- 3.9. [Viewing images](#)
 - 3.9.1. [Viewing a specific Channel](#)
 - 3.9.2. [Additional viewing options](#)
 - 3.9.2.1. [Colour and greyscale viewing](#)
 - 3.9.2.2. [Movie viewing across channels](#)
 - 3.9.2.3. [Channel configuration](#)
 - 3.9.2.4. [Image information](#)
 - 3.9.2.5. [Annotation View](#)
 - 3.9.3. [Magnification](#)
 - 3.9.3.1. [Magnifying the whole image](#)
 - 3.9.3.2. [Magnifying an area of the image](#)
 - 3.9.3.3. [Scale bar](#)

- 3.9.4. Viewing z-sections and timepoints
 - 3.9.4.1. Automated viewing of z-sections and timepoints
 - 3.9.4.2. Selecting z-section and timepoints
 - 3.9.4.3. Additional Movie Player options for z-section and timepoint viewing
- 3.9.5. Image Rendering options
- 3.10. The Hierarchy Viewer: viewing multiple images
 - 3.10.1. Viewing an image from the Hierarchy Viewer
 - 3.10.2. Using the Hierarchy Viewer
 - 3.10.2.1. Adjusting thumbnail display
 - 3.10.2.2. Display Tree View of images
 - 3.10.2.3. Sorting images
 - 3.10.2.4. Managing images in the Hierarchy Viewer
 - 3.10.2.5. Additional image information: the Working Area
- 3.11. Managing windows in OMERO.insight
- 3.12. Closing OMERO.insight

3.1. Getting to know the Data Manager

Every time you log in OMERO.insight, you will see Data Manager's default screen, which consists of several areas of interest as labelled in [Figure 3.1-1](#) .

1. The left-hand pane shows projects and datasets, category groups, categories or images in a hierarchical manner. (Note that on first accessing OMERO.insight, this pane will be empty until you create a project.)
2. The right-hand pane shows information relating to the currently selected project, dataset, category group, category or image; and will be blank if none exists or none is selected.
3. Above the two panes are three distinct navigational areas. From the top of the page, these are:
 - a. Application-wide toolbar. This gives access to options that remain constant throughout use of the Data Manager.
 - b. The **Projects** , **Categories** and **Images** tabs. These specify what information is shown in the left-hand pane.
 - c. Context-specific toolbar. This provides options specific to whether Projects and Datasets, Category Groups and Categories, or Images are being shown in the left-hand pane.
4. Finally, there are five application menus, each offering options based on the current status of OMERO.insight. The menus available are **File** , **Edit** , **View** , **Window** and **Help** .




Figure 3.1-1 : Data Manager, default screen with three projects listed

NB

If you wish to send a comment to the OMERO development team, open the **Help** menu and select **Send Comment**.

3.2. Viewing and editing user account details

You can make a limited amount of changes to your OMERO account details in the Data Manager.

At the top of the tree in the left-hand pane of the Data Manager is your own user name. Click on this to see your user account details, shown in the right-hand pane (see [Figure 3.2-1](#)). There are two tabs:

- **My Profile** shows basic personal information.
- **My Servers** shows all OMERO servers for which you have a user account.




Figure 3.2-1 : User Profile Editor




NB

The only edits you can make at present is to change your OMERO password using the form here. Future releases of OMERO will allow you to make additional changes to your account, which currently can only be made by users with OMERO administrator status. The ability to change from one server to another will also be added in future versions.

3.3. Managing projects and datasets

In [Section 2.3](#) we explained how to create projects and datasets as part of the Import process; OMERO.insight also allows you to create and manage projects and datasets.

The following icons are used in OMERO.insight:

-  denotes a project.
-  denotes a dataset.
-  denotes an image.

[3.3.1.Creating projects and datasets](#)

[3.3.2.Renaming projects or datasets](#)

[3.3.3.Removing projects or datasets](#)


[3.3.4.Expanding a project to see constituent datasets](#)

[3.3.5.Expanding a dataset to see constituent images](#)

[3.3.6.The Projects, Categories and Images tabs](#)

3.3.1. Creating projects and datasets

To create a project in OMERO.insight:

1. In the **File** menu, select **Create New project** . Or, select the  icon.
2. In the window that appears (see [Figure 3.3.1-1](#)), enter the name of the new project. You can optionally add a textual description of the project.
3. Select **Save** to confirm.
4. Your project should now be created ([Figure 3.3.1-2](#) shows a new project created and named DemoProject).




Figure 3.3.1-1 : Insight's 'Add a new project' window





Figure 3.3.1-2 : Data Manager showing details of a selected project

To create a dataset in OMERO.insight:

1. Select the project in which you want to create the dataset. The right-hand pane now shows information about the selected project (see [Figure 3.3.1-3](#)).
2. From the **File** menu, select **Add New Dataset** . Or, select the  icon.
3. In the window that appears, enter the name of the new dataset, and a textual description if you wish.
4. Select **Save** to confirm the addition.
5. The dataset should now be listed in the left-hand pane, under the relevant project (see [Figure 3.3.1-4](#)).




Figure 3.3.1-3 : Adding a new dataset to an existing project




Figure 3.3.1-4 : Data Manager showing one available project, containing one dataset

3.3.2. Renaming projects or datasets

To rename a project or dataset:

1. Select the project or dataset.
2. In the right-hand pane, edit the text in the **Name** field.
3. Select **Save** to confirm changes.

3.3.3. Removing projects or datasets

To remove a project or dataset:

1. In the left-hand pane of the Data Manager, select the project or dataset to be removed.
2. In the **Edit** menu, select Remove (or **Remove from current project** for a dataset). This removes the selected project or dataset. 'Orphaned Datasets' will be created to hold the removed dataset(s).
3. The removed projects or datasets will go to 'Orphaned Datasets', which appears on top of the tree view. The number in the bracket shows how many removed datasets are in.

NB

When you remove a project, the dataset(s) in it will be listed in the 'Orphaned Datasets' and therefore you will not see the name of the project but only the dataset(s). A project or dataset is only removed from a project - it is not deleted from the system.

3.3.4. Expanding a project to see constituent datasets

In the left-hand pane you might see projects listed but not their datasets ([Figure 3.3.4-1](#)). The number in square brackets after the project name is the number of datasets belonging to the project.

To see all datasets belonging to a project, click the **Expand** icon: ►.

All datasets associated with the selected project will now be shown ([Figure 3.3.4-2](#)). This icon will change appearance to ▼ to show that the project has been expanded to show datasets - clicking the icon again will collapse the display to show just the project again. Note that in [Figure 3.3.4-1](#), the AnotherDemoProject image has no datasets - so cannot be expanded.




Figure 3.3.4-1 : Project listing without datasets




Figure 3.3.4-2 : Project expanded to show datasets

3.3.5. Expanding a dataset to see constituent images

The number in brackets after a dataset name is the number of images belonging to that dataset.

To see all images belonging to a dataset, click the **Expand** icon as above - the images will now be listed ([Figure 3.3.5-1](#)).





Figure 3.3.5-1 : Expanded dataset showing images

NB


The file path name shown, in particular the number of directories preceding the filename, reflects the settings specified when importing using OMERO.importer. See [Section 2.3](#) for choosing display options for lists of image filenames.

3.3.6. The Projects, Categories and Images tabs

You will see that in [Figure 3.3.5-1](#), above the left-hand pane there are two tabs - **Projects** and **Categories** visible, plus an arrow tab .

There should in fact be three tabs - the hidden one is the **Images** tab. If you only see two tabs, clicking on this tab gives you a menu showing all three options, allowing you to select the **Images** tab. Alternatively, hold down the mouse pointer in the space between the left and right-hand panes, and drag to the right to widen the left-hand pane until all three tabs appear (as in [Figure 3.3.6-1](#)).

NB

The arrow tab is reversed when only the **Categories** and **Images** tabs are shown: . In this case, click the tab to access the **Projects** tab.

The **Images** tab is discussed further in [Section 3.7](#), and the **Categories** tab is discussed further in [Section 3.8](#).





Figure 2.3.6-1 : Expanded left-hand pane showing three tabs

3.4. Viewing other people's images

OMERO supports collaborative work by allowing users to share images among group users. Assuming the appropriate permissions have been granted by the image owner, it will be possible for

- You to select another user and view their images;
- Other people with an OMERO account to view your images for which you have enabled permission for others to view.

To select another user, view, and - if desired - annotate their images:

- Click on the **Switch user** icon . Or, open the **File** menu and select **Switch user** ;
- Choose the OMERO group in which the user belongs;
- Select the user from the menu that appears (see [Figure 3.4-1](#)), and select **Apply** .

The user's data will appear in a new Data Manager window.




Figure 2.4-1 : Switch User selection menu

3.5. Additional information about projects, datasets and images

You can view additional information to a selected project, dataset or image. This is available in the right hand pane of the Data Manager:

- The **Properties** tab shows you the name and description of the selected project, dataset or image. In future versions of OMERO.insight, you will be able to set permission levels for accessing the selected project, dataset or image (see [Figure 3.5-1](#)).
- The **Annotations** tab allows you to see and add annotations to the selected dataset or image. You cannot add an annotation to a project. For more on Annotations, see [Section 3.6](#).
- The **Info** tab is available when an image is selected. This provides information about the image, including X, Y dimensions, number of z-sections and timepoints, pixel sizes and number of emission wavelengths.




Figure 3.5-1 : Viewing permissions information for a selected image

3.6. Annotations


OMERO lets you add annotations - textual notes - to any image or dataset in your collection. You can also add annotations to any other images that you have permission to see.

[3.6.1. Viewing annotations](#)

[3.6.2. Annotating a single image or dataset](#)

[3.6.3. Annotating multiple images or datasets](#)

3.6.1. Viewing annotations

The  icon shows that a dataset has one or more annotation (see `TestDataset1` in [Figure 3.3.4-1](#) for an example).

The  icon shows that an image has one or more annotations.

To view annotations in the Data Manager:

1. Select the image or dataset for which you wish to see the annotations.
2. Select the Annotation tab in the right-hand pane.
3. A window appears with two panes (see [Figure 3.6.2-1](#)):
 - The left-hand pane shows a tree-list of all annotations for the selected image, dataset or project, plus date and time the annotation was made. Annotations are grouped by users, allowing you to see any annotations made by other users.
 - The right-hand pane provides an area for you to add a new annotation; it also shows the content of all existing annotations.

You can also view an image's annotation(s) in the Image Viewer - see [Section 2.4.1](#), or in the Hierarchy Viewer - see [Section 3.10](#).

3.6.2. Annotating a single image or dataset

To add a new annotation to a selected image or dataset:

1. Making sure the **Annotation** tab is selected, type in a new annotation in the right-hand pane.
2. On completing the annotation, select the **Save** button to confirm.

On saving, the annotation will be 'stamped' with the user who created the annotation, and the time the annotation was created.





Figure 2.6.2-1 : Adding an annotation to an image

You can also add an annotation to an image in the Image Viewer - see [Section 3.9.2.5](#), and in the Hierarchy Viewer - see [Section 3.10.2.5](#).

3.6.3. Annotating multiple images or datasets

OMERO allows you to add an annotation to a selection of images or datasets, all at once.

To do this,

1. Select the images or datasets.
2. Select the toolbar icon .
3. This opens up the Annotate dialog box (see [Figure 3.6.3-1](#)). It shows you, in three panes:
 - a. the list of images or datasets selected,
 - b. a tree view showing names of users who have added annotations; expanding a user name shows the time of each annotation added.
 - c. space to add a new annotation or see the text of any existing annotation.
4. Enter the annotation text in the right hand pane.
5. Select **Save** ; a message box appears (see [Figure 3.6.3-2](#)). Choose the **All** option to save the annotation for all selected images or datasets; or **One** to save the annotation for only the first selected item - the one named in the message box.




Figure 3.6.3-1 : Annotating multiple items








Figure 3.6.3-2 : Multiple annotation confirmation

3.7. Categorising images

OMERO.insight allows you to create categories for use in managing your images, as a separate means of organisation from the Project/Dataset structure. To do this, first you create a category group, and then create one or more categories within the category group. Once you have some Categories, you can then use these to categorise your images.

Icons used:

-  denotes a category group.
-  denotes a category.
-  denotes a categorised image.
-  denotes a categorised image that also has one or more annotations.

[3.7.1.Creating category groups](#)

[3.7.2.Creating categories](#)

[3.7.3.Removing categories and category groups](#)

[3.7.4.Categorising images](#)

[3.7.4.1.Categorising a single image](#)


[3.7.4.2.Categorising multiple images](#)

[3.7.4.3.Viewing images in a category](#)

[3.7.4.4.Removing an image from a category](#)

3.7.1. Creating category groups

Creating a category group is a similar process to creating a Project:

1. Select the **Categories** tab. This will bring up a list of existing Category Groups (or will be empty if none exist).
2. Then:
 - Either click the **Create Category Group** toolbar button .
 - Or go to the **File** menu, and select the **New Category Group...** option.
3. In the right-hand pane, enter the Category Group name, and an optional textual description ([Figure 3.7.1-1](#)).
4. Select **Save** to confirm.
5. Your Category Group should now be listed in the left-hand pane.




Figure 3.7.1-1 : Adding a Category Group

3.7.2. Creating categories

Creating a category is a similar process to creating a dataset:


1. Select the category group into which the category should go (i.e. make sure it is highlighted in the left-hand pane).
2. Then:
 - Either click the **Create Category** toolbar button .
 - Or go to the **File** menu, and select the **New Category...** option.
3. In the right-hand pane, enter the Category name, and an optional textual description.
4. Select **Save** to confirm.
5. Your Category should now be listed in the left-hand pane, under the appropriate Category Group.

Figure 3.7.2-1 shows a list of category groups with categories. The number in brackets after each category group name indicates how many categories belong to that group; similarly the number after each category name indicates how many images belong to that category.




Figure 3.7.2-1 : List of category groups with categories

3.7.3. Removing categories and category groups

To remove a category from a category Group:

1. Select the category to be removed.
2. In the **Edit** menu, select **Remove**.
3. The category will be removed from the category group. 'Orphaned Categories' will be created to hold the removed category.
4. The removed category will go to 'Orphaned Categories', which appears on top of the tree view. The number in the bracket shows how many removed categories are in.
5. Similarly, to remove a category group, select the category group to be removed, and use the **Edit** menu as above.

NB

A category or category group is only removed from a project - it is **not deleted** from the system.

3.7.4. Categorising images

Once you have created one or more categories, you can categorise your images.

[3.7.4.1.Categorising a single image](#)



[3.7.4.2.Categorising multiple images](#)

[3.7.4.3.Viewing images in a category](#)

[3.7.4.4.Removing an image from a category](#)

3.7.4.1. Categorising a single image

To categorise an individual image:

1. Select the image filename.
2. Then:
 - Either in the **Edit** menu, select **Categorise**.
 - Or select the  toolbar button and then **Categorise** from the pop-up menu that appears.
3. In the right-hand pane, you will initially see a list of available category groups. Select the appropriate category group and expand it by selecting the **Expand** button .
4. Tick all categories you wish to add the selected image to. (**Select All** and **Deselect All** buttons are available to speed up the task of selection).
5. Select **Save** to confirm the categorisation.

3.7.4.2. Categorising multiple images

If you wish to add more than one image to the same category or categories, the steps described in [Section 3.7.4.1](#) can be applied for multiple selected images.

3.7.4.3. Viewing images in a category

To view all images in a selected category:

1. Select the **Categories** tab.
2. In the left-hand pane, expand the category group and select your chosen category.
3. The list will expand to show all images currently in that category (see [Figure 3.7.4.3-1](#)).





Figure 3.7.4.3-1 : Viewing all images in a selected category

3.7.4.4. Removing an image from a category

To de-categorise an individual image:

1. Select the image filename.
2. Then:
 - Either in the **Edit** menu, select **Decategorise**.
 - Or select the  toolbar button and then **Decategorise** from the pop-up menu that appears.
3. In the right-hand pane, you will initially see a list of available Category Groups. Select the appropriate category group and expand it by selecting the **Expand** button: ►.
4. Tick all categories from which you wish to **remove** the selected image. (**Select All** and **Deselect All** buttons are available to speed up the task of selection).
5. Select **Save** to confirm the de-categorisation.

3.8. Sorting and finding images

As you build up collections of images, you may wish to sort them into manageable groups, or find a specific image or group of images in your collection. OMERO.insight allows you to sort images by various techniques, and also to search for a specific image(s).

[3.8.1.Sorting images](#)

[3.8.2.Retrieving selected images](#)

[3.8.3.Finding images with Find in Tree](#)


3.8.1. Sorting images


A number of options are available for sorting a collection of images. These are provided in the context-specific toolbar (labelled as 3c in [Figure 3.1-1](#)) directly below the **Projects**, **Categories** and **Images** tabs ([Figure 3.8.1-1](#)), and are available to a list of images.



Figure 3.8.1-1 : Toolbar providing sort options

These options are:

 - Alphabetical sort. Select this option to sort image file names in alphabetical order. In the illustration in [Figure 3.8.1-1](#), this option is selected, and hence the icon appears shaded.

 - Date sort. Select this option to sort image file names in order of the date they were taken on the microscope - and if this information is not available, in order of the date of import into OMERO.

NB

If the list of images shows more than one open dataset or category, images are sorted alphabetically or by date only within their parent dataset or category - although the order in which datasets or categories appear may change.


 - This option allows you to toggle between showing a truncated path name and full path name for each listed image. [Figure 3.8.1-2](#) and [Figure 3.8.1-3](#) show the difference in image display names.



Figure 3.8.1-2 : Truncated image pathname



Figure 3.8.1-3 : Full image pathname


NB

The actual number of directories shown in the full image pathname depends on the option chosen when importing the image using OMERO.importer.

▼ - This option expands to reveal a menu with further options for viewing images, discussed in more detail in [Section 3.8.2](#). It is only visible when the **Images** tab is selected;

☐ - This option allows you to quickly collapse the current list of image filenames to show only parent projects or category groups.

NB

If at any time the left-hand display appears not to be showing the information you expect, select  or **Refresh Current Tree** from the File menu to refresh the display.

3.8.2. Retrieving selected images

You can retrieve selected images from your collection of imported data by filtering out images based on the categories they belong to or by datasets.




Figure 3.8.2-1 : Filter images retrieval window

Clicking the **Images** tab (see [Section 3.3.2](#)) results in a new window being displayed - the **Filter Images Retrieval** window ([Figure 3.8.2-1](#)). This allows you to specify which image filenames you would like to see listed in the left-hand pane. You have three choices:

1. Select images from chosen datasets.
2. Select images from chosen categories.
3. Select all images in your collections.

Select the **Image** menu button ▼ to see the **Image** menu (shown in [Figure 3.8.2-2](#)). This allows you to specify how Filter Images Retrieval will work.

On choosing either of the first two options in the list above, the **Filter Images Retrieval** allows you to select those datasets or categories from which you wish to retrieve images. All image filenames found will then appear in the left-hand pane.



Figure 3.8.2-2 : Menu for configuring Filter Images Retrieval

3.8.3. Finding images with Find in Tree

The **Find in Tree** feature works in a similar way to the 'Find in Page' feature provided by many Web browsers. It allows you to search for a text string within all items displayed in the left-hand pane (Figure 3.8.3-1).





Figure 3.8.3-1 : Find in Tree request showing results

To conduct a search:

1. In the **Edit** menu, select **Find in Tree**. A form will appear at the bottom of the **Data Manager** window.
2. Type the text string you wish to search for in the **Find** : text box.
3. Use the arrow icon  to select whether you wish to find a pattern in image names or descriptions.
4. The **Match Case** checkbox can be checked if you want to ensure that image filenames are returned only if they match the case of the text string you specify.

The search will be dynamically conducted, reporting how many images were found that match your search criteria. The first image found will be highlighted (Figure 3.8.3-1); use the **Find Next** or **Find Previous** buttons to move through each image found. If no images are found, a Phrase Not Found message is shown.

NB

The Find in Tree feature can also work with datasets, projects, categories and category groups - i.e. whatever is currently listed in the left-hand pane.

3.9. Viewing images

In [Section 2.4.1](#) we described how you can view an image in constituent channels, time points or z-sections in OMERO's Image Viewer.

[Section 2.4.2](#) described how thumbnails of a selection of images can be viewed using the Hierarchy Viewer.

This section provides further information on viewing images using the Image Viewer.




Figure 3.9-1 : The Image Viewer, standard view

- 3.9.1. Viewing a specific Channel
- 3.9.2. Additional viewing options
 - 3.9.2.1. Colour and greyscale viewing
 - 3.9.2.2. Movie viewing across channels
 - 3.9.2.3. Channel configuration
 - 3.9.2.4. Image information
 - 3.9.2.5. Annotation View
- 3.9.3. Magnification
 - 3.9.3.1. Magnifying the whole image
 - 3.9.3.2. Magnifying an area of the image
 - 3.9.3.3. Scale bar
- 3.9.4. Viewing z-sections and timepoints
 - 3.9.4.1. Automated viewing of z-sections and timepoints

[3.9.4.2. Selecting z-section and timepoints](#)

[3.9.4.3. Additional Movie Player options for z-section and timepoint viewing](#)

[3.9.5. Image Rendering options](#)

3.9.1. Viewing a specific Channel

The channel buttons (shown as the four coloured squares labelled 457, 528, 617, 685 in [Figure 3.9-1](#)) enable you to **turn on or off** specific channels for multi-channel images. Turning on or off a channel will result in an immediate visual change to the image shown in the Image Viewer.

The colour band selected for a given channel corresponds to the emission wavelength of the channel. If this information is not available, the channels will be mapped to red, green and blue. The colour used to display any channel can be customised using the Colour Picker ([Section 3.9.2](#)).

Channels can be turned on or off by clicking the relevant channel selection button, aligned vertically on the left edge of the **Image Viewer** window. Buttons show the colour associated with the channel, plus wavelength in nanometres (if this information is available).



3.9.2. Additional viewing options

- [3.9.2.1.Colour and greyscale viewing](#)
- [3.9.2.2.Movie viewing across channels](#)
- [3.9.2.3.Channel configuration](#)
- [3.9.2.4.Image information](#)
- [3.9.2.5.Annotation View](#)

3.9.2.1. Colour and greyscale viewing

The top two Image Viewer toolbar buttons change appearance depending on the current state of the image:

 (alternative state is ) **enable toggling between colour model and greyscale display:**



- To switch from colour display to greyscale, select .
- To switch from greyscale to colour display, select .

NB

The above options can also be chosen by opening the **Controls** menu and selecting the **Models** option. This allows you to choose between **Colour** and **Greyscale** options.


3.9.2.2. Movie viewing across channels

 (alternative state is ) enable viewing single-channel views of the image, as a movie:

1. To start the movie, select . This will display the image for a short period using each of the currently selected channels in turn.
2. The movie runs on a loop, and will continue until you stop it. To stop the movie, select . The image then reverts to its appearance before the movie started.

This option is available for the Image Viewer's Standard View and Annotation View modes. Movie options for viewing z-sections and timepoints are described in [Section 3.9.4](#).

3.9.2.3. Channel configuration

 The Colour Picker button allows you to configure the **channel corresponding to a specific channel button**. To associate a specific channel with a channel button:

1. Click on the **Colour Picker** button.
2. In the menu that appears, choose which channel to adjust.
3. The **Colour Picker** window opens ([Figure 3.9.2.3-1](#)).
4. You can then select a colour in one of three ways, each available by selecting one of the toolbar buttons at the top of the window. These options are:
 - a. Using the HSV colour wheel;
 - b. Using RGB colour sliders (shown in [Figure 3.9.2.3-1](#));
 - c. Showing the colour list.
5. Once happy with your settings, select **Accept** to confirm the changes, or **Revert** to ignore the setting changes you have just made.
6. You should now see the channel change applied to the relevant channel button.



Figure 3.9.2.3-1 Colour Picker





Figure 3.9.2.3-2: Channel Info window

The Colour Picker can also be accessed by double-clicking on a channel button.

Right-clicking on a channel button gives access to a menu from which you can choose to bring up the Colour Picker or to display additional information about the channel ([Figure 3.9.2.3-2](#)).

3.9.2.4. Image information

To view basic information about an image displayed in the Image Viewer, select the **Image Info** button  : The Image details window then appears (see [Figure 3.9.2.4-1](#)).




Figure 2.9.2.4-1 : Image information window

3.9.2.5. Annotation View

One advantage of the Annotation View mode of the Image Viewer is that it allows you to add annotations to an image while looking at it in some detail (see [Figure 3.9.2.5-1](#)).

In this view, the Annotations panel is shown in a similar way to the Data Manager, showing any existing annotations plus the name of the user who added the annotation and the date they were added; like in Data Manager you can add annotations to the image as desired.

Note that the annotations exist as separate text attributes of the image - the image file itself is not annotated.




Figure 3.9.2.5-1 : Image Viewer Annotation View

3.9.3. Magnification

It is possible to view areas of the image in more (or less) detail by setting the magnification of the image or by using the lens feature. This feature works for all three Image Viewer modes: Standard View, Annotation View and Split View.

[3.9.3.1.Magnifying the whole image](#)

[3.9.3.2.Magnifying an area of the image](#)

[3.9.3.3.Scale bar](#)

3.9.3.1. Magnifying the whole image

To magnify the whole image, use the Zoom feature:

1. Open the **Zoom** menu.
2. Choose from one of the predefined magnification levels.
3. The display of the Image Viewer will change to show the selected image ([Figure 3.9.3.1-1](#)).

This works in a similar fashion in Standard View, Annotation View and Split View modes.

For increased magnification, you may need to use the Image Viewer's scroll bars to view all parts of the image; to avoid this, you can resize the **Image Viewer** window to show an increased area of the image.





Figure 3.9.3.1-1 : Image Viewer showing magnified image

3.9.3.2. Magnifying an area of the image

The Lens feature allows you to see an area of the image at a greater magnification level than the Zoom feature. It also allows you to see the magnified section alongside the image as a whole. It works in a similar fashion in Standard View, Annotation View, and Split view.

1. Open the Zoom window:
 - Either select the **Lens** toolbar button: 
 - Or open the **Controls** menu and select the **Lens** option.
2. The **Zoom** window will now appear beside the **Image Viewer** window, and shows a magnified area of the image.

Below the image is additional information on the dimensions of the magnified image. The area of the magnified image is outlined in the main **Image Viewer** window ([Figure 2_9_3_2-1](#)).

To redefine the area of the image being magnified:

1. Click the mouse pointer on the highlighted area in the main Image Viewer.
2. Drag the highlighted area to the area of the image you wish to see magnified.
3. The **Zoom** window will be updated to reflect the change in area.

To change the size of the magnified area:

1. In the **Zoom** window, select the **Lens** menu.
2. Choose from one of the predefined window sizes.

NB

You may need to scroll or resize the **Zoom** Window to see all of the magnified area.

To change the magnification level:

1. In the **Zoom** window, select the **Zoom** menu.
2. Choose from the predefined list of magnification options.
3. The dimensions shown will be updated to reflect your choice.

To change the units of the dimensions shown in the **Zoom** Window, select the **Units** menu and choose between **microns** and **pixels**. You can also zoom using the mouse

wheel, if your operating system supports this.




Figure 3.9.3.2-1 Image Viewer and Zoom window

3.9.3.3. Scale bar

The Image Viewer by default includes a scale bar in the bottom right corner of the image. In [Figure 3.9.3.1-1](#), the scale bar shows a length of 5 nanometres - the default setting. You can configure how the scale bar is displayed, using the **View** menu.

To **remove** the scale bar from the current image display:

1. Select the **View** menu.
2. Select the **Show Scale bar** option.

To **show** the scale bar, repeat the steps above.

To **change the length** of the scale bar:

1. Select the **View** menu.
2. Select **Scale bar length (in nanometres)**
3. Then:
 - Either choose a length from the options available,
 - Or choose **Custom**, and in the pop-up window that appears, enter your preferred length in the **Value** field and press **Enter**.
4. The scale bar length and label will now be adjusted.

To **change the colour** of the scale bar:

1. Select the **View** menu.
2. Select **Scale bar colour** option.
3. Choose from one of the colour options available.
4. The scale bar colour will now be adjusted.

NB

The scale bar will not appear if there is not enough space.

3.9.4. Viewing z-sections and timepoints

For images with multiple z-sections and/or timepoints, the Image Viewer can allow manual or automated viewing of each section. Z-sections and timepoints can be viewed separately or together.

[3.9.4.1. Automated viewing of z-sections and timepoints](#)

[3.9.4.2. Selecting z-section and timepoints](#)

[3.9.4.3. Additional Movie Player options for z-section and timepoint viewing](#)

3.9.4.1. Automated viewing of z-sections and timepoints

In [Section 2.4.1.1](#), we outlined how the z-section or timepoint being viewed can be manually configured, using the sliders provided by the Image Viewer.

You can also view each of the image's composite z-sections or timepoints **as a movie**. Each z-section or timepoint is displayed in sequence for a short time period to form the movie.








Figure 3.9.4.1-1 : Movie Player

To play z-sections or timepoints as a movie:

1. In the **Image Viewer** window:
 - Either select the **Play Movie** button: .
 - Or open the **Controls** menu and select the **Movie** option.
2. The **Movie Player** window appears ([Figure 3.9.4.1-1](#)).
3. Select the **Play** button  to play the movie.
4. Select the **Stop** button  to stop the movie.
5. When a movie is playing, the **Play** button becomes a **Pause** button .

3.9.4.2. Selecting z-section and timepoints

A third option for viewing different z-sections and timepoints exists when an image is shown in Standard View and Annotation View. Holding down the mouse button and dragging the mouse vertically up or down the image moves through z-sections; dragging horizontally moves through timepoints. Dragging diagonally will simultaneously change z-sections and timepoints.

3.9.4.3. Additional Movie Player options for z-section and timepoint viewing

The Movie Player allows you to make additional adjustments to the movie being played.

To **configure how the movie is played**, the **Play** menu gives you several choices:

- **Forward** shows each z-section or timepoint in turn, once only.
- **Backward** shows each z-section or timepoint in turn, once only, but in the opposite order to **Forward**.
- **Loop** shows each z-section or timepoint in turn **Forward**, but continuously until you choose to stop the movie.
- **Loop Backward** shows each z-section or timepoint in turn **Backward**, but continuously until you choose to stop the movie.
- **Back and Forth** shows each z-section or timepoint in turn, **Forward** and then **Backward**, until you choose to stop.

Table 3.9.4.3-1 shows the difference in the Play options for an example image with 5 z-sections numbered 1, 2, 3, 4, 5.

Play option	Frame order
Forward	1, 2, 3, 4, 5
Backward	5, 4, 3, 2, 1
Loop	1, 2, 3, 4, 5, 1, 2, 3, 4, 5, 1, 2...
Loop Backward	5, 4, 3, 2, 1, 5, 4, 3, 2, 1...
Back and forth	1, 2, 3, 4, 5, 4, 3, 2, 1, 2...

Table 3.9.4.3-1 : Movie Player Play options


To **specify which sections or timepoints should be included** in the movie:

1. Make sure the appropriate option is selected (**Across Z** for z-sections only; **Across T** for timepoints only, and **Across Z and T** to play a movie showing all z-sections for each timepoint).
2. To specify which individual z-section or timepoint is respectively the first and last to be shown in the movie sequence:
 - Either move the left-hand slider button to select the first z-section (or timepoint) and the right-hand slider button to select the last z-section (or timepoint);
 - Or use the **Start** and **End** fields to type the number of the first z-section (or timepoint) and last z-section (or timepoint).

3.9.5. Image Rendering options

Options are also available to adjust rendering properties. Here, you adjust how the raw pixels' intensity values are mapped to the image displayed on your monitor.

These are available by:

- Either selecting the **Rendering Options** toolbar button: .
- Or opening the **Controls** menu and selecting the **Renderer** option.

This brings up the **Display Settings** window (shown in [Figure 3.9.5-1](#)).




Figure 3.9.5-1 : Display Settings

Adjusting the rendering parameters will result in an immediate visual change to the image shown in the Image Viewer, except when adjusting the values of the horizontal slider. By default, the image shown in the Image Viewer will be updated when the knobs of the horizontal slider are released. For an immediate update, check the **Immediate Update** check box.

The horizontal slider allows you to specify start and end values for the interval of the raw data you wish to map. This is specified separately for each channel. Alternatively you can manually enter values in the **Start** and **End** fields.

NB

Currently you can only select values between the displayed **Min** and **Max** values (0 and 2484 in [Figure 3.9.5-1](#))

The vertical slider allows you to specify a range of the colour space i.e. a sub-interval of [0, 255]. This allows you to increase or decrease the overall brightness of the image.




Figure 3.9.5-2 : Display Settings window showing advanced options

Advanced image rendering options are available by selecting the **Show Advanced Options** button (Figure 3.9.5-2), This expands the **Display Settings** window to include options to:

- Select the mapping curve (from a choice of linear, polynomial, exponential or logarithmic) for a channel.
- For polynomial or exponential curves, you can modify the shape of the curve for a channel, by adjusting the gamma value.
- Adjust bit depth.
- Turn on or off noise reduction.

NB

Bit depths and values for the vertical slider are the same across all channels; the other parameters are specified for each channel.

NB

The **Device Settings** tab is not functional in the current version of OMERO.insight, but will in future versions enable features such as reverse intensity and plane slicing.

Use the **Save** button to save rendering settings back to the database for future use.

Use the **Undo All** button to reset to the default rendering settings. Note that the default rendering settings are **not** the ones previously saved but the internal defaults of the rendering facility.

3.10. The Hierarchy Viewer: viewing multiple images

For viewing a selection of images, the selection initially appears as a set of thumbnails in a new window - the Hierarchy Viewer. What you see in the Hierarchy Viewer depends on what you selected. [Table 3.10-1](#) summarises how thumbnails are displayed in the Hierarchy Viewer by default using the **Hierarchical Layout** option.

Selection	Hierarchy Viewer shows...
One or more images individually selected	All images in a flat view layout (see Figure 2.4.1-3)
One dataset or category	All images in one container
Multiple datasets or categories	Multiple thumbnail containers, one for each dataset or category
One project or category group	Multiple thumbnail containers, one for each dataset in the project or category group
Multiple projects or category groups	Multiple projects or category groups Multiple thumbnail containers; one for each dataset in each project/category group (see Figure 3.10-1)

Table 3.10-1 : Image selection method in Hierarchy Viewer display

The Hierarchy Viewer offers an alternative layout - **Flat Layout** option. This is a flat grid display of all displayed thumbnails, with no containers.

To select your preferred layout option, open the **View** menu, select Layout and choose between **Flat** and **Hierarchical**.




Figure 3.10-1 : Hierarchy Viewer showing multiple containers

- 3.10.1. Viewing an image from the Hierarchy Viewer
- 3.10.2. Using the Hierarchy Viewer
 - 3.10.2.1. Adjusting thumbnail display
 - 3.10.2.2. Display Tree View of images
 - 3.10.2.3. Sorting images
 - 3.10.2.4. Managing images in the Hierarchy Viewer
 - 3.10.2.5. Additional image information: the Working Area

3.10.1. Viewing an image from the Hierarchy Viewer

Once you see thumbnails in the Hierarchy Viewer, you can view an individual image in more detail in the Image Viewer through the following options:

1. Double-click on the image's thumbnail.
2. Select the image thumbnail and then select **View** from the **Edit** menu.
3. Right-click on the image thumbnail to display the **Edit** menu as for option 2.

The Image Viewer will then display the image as shown in [Figure 2.4-1](#)

3.10.2. Using the Hierarchy Viewer

The Hierarchy Viewer has many additional features to allow access to information about the current image selection.

- 3.10.2.1. [Adjusting thumbnail display](#)
- 3.10.2.2. [Display Tree View of images](#)
- 3.10.2.3. [Sorting images](#)
- 3.10.2.4. [Managing images in the Hierarchy Viewer](#)
- 3.10.2.5. [Additional image information: the Working Area](#)

3.10.2.1. Adjusting thumbnail display


You can adjust the way the sets of thumbnails are displayed in the Hierarchy Viewer in a number of ways:

Moving a container: Select the container and drag it with the mouse to wherever you wish within the *Hierarchy Viewer* window.

Resizing a container: Click a corner of the container and drag the mouse to resize the container.




Magnifying an individual thumbnail: To enlarge a single thumbnail:

1. Select the **Magnify** button .
2. Move the mouse pointer over the thumbnail to be magnified. An enlarged version appears.
3. If you have a mouse wheel, you can increase or decrease the magnification factor by scrolling the wheel.


Continuous movement of the mouse pointer will magnify in turn each image the pointer passes over.

To keep a specific thumbnail on screen:

1. Select the pin-up icon .
2. The thumbnail will now remain on screen regardless of the position of the mouse pointer.

If you have a mouse wheel, you can increase or decrease the magnification factor of the pinned thumbnail by scrolling the wheel.

To remove a pinned-up thumbnail:


1. Select the Close button  at the top of the thumbnail window.
2. The pinned up thumbnail is removed from display.

NB

Closing the *Hierarchy Viewer* window also removes all pinned-up thumbnails.

Change the size of all thumbnails in a container: You can enlarge or reduce the size of each thumbnail in a selected container (this includes all thumbnails in sub-containers).


To **increase** the size of all thumbnails:

1. Select the container.
2. Select the **Zoom In All Images...** button .

To **decrease** the size of all thumbnails:

1. Select the container.
2. Select the **Zoom Out All Images...** button .

To **reset** the size of all thumbnails:

1. Select the container.
2. Select the **Reset Thumbnail Size...** button .
3. Thumbnails will return to the default size.

View one thumbnail at a time in a container: Click on the **Switch to Single-view mode** button. The display changes to show only one thumbnail in the selected container.

To **change the thumbnail currently in view:**


1. Click the **Switch to Single-view mode** button again.
2. Choose the **Select** option from the menu that appears.
3. Then select the filename of the image you wish to view from the submenu that appears.
4. The displayed thumbnail changes.

To **return to viewing multiple thumbnails:**

1. Click the **Switch to Single-view mode** button again.
2. Choose the **Multi-view mode** option from the menu that appears.
3. You will now see all thumbnails in the container.

Collapse a container: Click on the **Collapse** button at the top of the container you wish to collapse. This will temporarily remove all thumbnails from view and reduce the size of the container. Click on the same icon again (it is now an **Expand** button) to bring the thumbnails back.

3.10.2.2. Display Tree View of images

 Selecting the **Display Tree View** option opens a pane where you can view the files currently shown in the Hierarchy Viewer as a tree structure - much like the left-hand pane of the Data Manager.

When the Tree View is visible, select the **Display Tree View** button again to remove this pane.

3.10.2.3. Sorting images

Like the Data Manager, images in the Hierarchy Viewer can be sorted within a set by date or name (see [Section 3.8.1](#)).



- Alphabetical sort. Select this option to sort image file names in alphabetical order.



- Date sort. Select this option to sort image file names in order of the date they were taken on the microscope - and if this information is not available, in order of the date of import into OMERO.

3.10.2.4. Managing images in the Hierarchy Viewer

In the Hierarchy Viewer, you can perform management actions on a single image or multiple images:

- Categorise or decategorise an image or selection of images.
- View and edit annotations for an image or selection of images.
- View property information of an individual image.
- Remove an image from its current dataset.

To perform any of these tasks, you can:

- Select one or more images in a container, and then open the **Edit** menu to select the operation of your choice.
- Or, right-click on a single image to see the **Edit** menu as above.


Icons are used to indicate the presence of category and annotations for any image appearing as a thumbnail in the Hierarchy Viewer; this iconic information is preserved for pinned up thumbnails.

Clicking on an icon will bring up the corresponding tab in the Working area (see [Section 3.10.2.5](#))

3.10.2.5. Additional image information: the Working Area

The Working Area is an area at the bottom of the Hierarchy Viewer window where detailed information about the currently selected image is available. Any image with a thumbnail shown in the Hierarchy Viewer can be selected by single-clicking or double-clicking the image.

To show the Working Area ([Figure 3.10.2.5-1](#)):

1. Select the **Working Area** toolbar button  to show the Working Area; when the Working Area is visible, select this button again to hide it;
2. Use your mouse to drag the Working Area to the desired size.




Figure 3.10.2.5-1 : Hierarchy Viewer showing Working Area

The Working Area (illustrated in [Figure 3.10.2.5-1](#)) provides similar information to the right-hand panel of the Data Manager. There are five tabs, each providing access to a specific Working Area feature, and each described below.

1. **Annotation:** Selecting this tab views all current annotations for the selected image. You


can add additional annotations or delete an annotation you have previously entered. For more details see [Section 3.6](#). This tab is selected if you click on the **Annotation** icon for a thumbnail.

2. **Categorisation:** This enables you to see the categories the currently selected image belongs to. You can then declassify the image's categorisation in a similar way to the Data Manager (see [Section 3.7](#)). This tab is selected if you click on the **Categorisation** icon for a thumbnail.

NB

To categorise an image or collection of images you need to use the **Edit** menu.

3. **Find:** This feature enables you to search within the selection of images shown in the Hierarchy Viewer. The find works in a similar way to the Data Manager Find feature (discussed in [Section 2.8.2](#)). Results are displayed in the **Results** panel to the right of the Find form.
4. **Editor:** This enables you to view and edit Properties and Permissions information (see [Section 2.5](#) for more details).
5. **Info:** Shows additional information about the image, including:
 - a. Number of pixels along X and Y axes;
 - b. Number of z-sections;
 - c. Number of timepoints;
 - d. Size of a pixel in microns;
 - e. Emission wavelengths (if available).

The Working Area can be set to automatically show information for any thumbnail when the mouse pointer hovers over that thumbnail. To enable this functionality, select the  button.

To stop this behaviour, select the button again.

3.11. Managing windows in OMERO.insight

As you work with images in OMERO.insight, you may end up with several open windows. The **Windows** menu, available at all times, shows all windows you have currently open in OMERO.insight, and allows you to jump between windows.

3.12. Closing OMERO.insight

To end a session using OMERO.insight, open the **File** menu in the Data Manager and select **Quit the Application** ; or, close the Data Manager window.

NB

Whenever you attempt to start a new action without saving edits or additions, you will be prompted to save or cancel the changes you made.

4. Feedback reporting

[4.1.Help Information](#)

[4.2.Feedback Facility](#)

4.1. Help Information

Help information is not currently available through the Data Manager **Help** menu; but you can send feedback by opening the **Help** menu and select **Send Comment**.

4.2. Feedback Facility

This Beta version of OMERO.importer and OMERO.insight has been rigorously tested to ensure it works as expected. Errors however may occur and a window will appear ([Figure 4.2-1](#)) inviting you to submit feedback about the error.

Providing this information is not required, but will help the development team identify and overcome the cause of the error. Submitting your email address is optional, and if you do, this information will only be used to contact you for more details about what you were doing when the error occurred.


The image shows a macOS-style window titled "Comment". It has two tabs: "Comments" and "Error Message", with "Error Message" selected. On the left is a large red "X" icon. The text inside the window reads: "An error message has been generated by the application." followed by "To help us improve our software, please fill out the following form. Your personal details are purely optional, and will only be used for development purposes." and "Please note that your application may need to be restarted to work properly." Below this is an "Email:" label followed by a text input field and the word "(Optional)". Underneath is the label "What you were doing when you crashed?" followed by a large text area. At the bottom right are "Cancel" and "Send" buttons.

Figure 4.2-1 : Error feedback form

5. Background information

This User Guide concentrates on providing a practical guide to managing, viewing and manipulating image in OMERO, but the following information in this section gives a brief outline of the principles and concepts used by OMERO.

[5.1.What is OMERO?](#)

[5.2.The OMERO Environment: client and server](#)

[5.3.5-Dimensional images](#)

[5.4.The OMERO Data Model and Hierarchies](#)

5.1. What is OMERO?

OMERO is a set of software tools that supports image data management, visualisation and annotation. OMERO tools include:

- an OMERO Server;
- and a series of client applications:
 - OMERO.webadmin;
 - OMERO.importer;
 - OMERO.insight.

5.2. The OMERO Environment: client and server

OMERO's design follows a standard client-server architecture. A single installation of an OMERO server will usually be used for an entire laboratory or imaging facility. Image data and metadata are typically stored on a central computer running the OMERO server, and then accessed via a standard Ethernet network using OMERO client applications that run on a user's workstation or laptop computer.

The OMERO Server manages all image metadata (date, size, channel names, etc.) but also contains an image rendering facility that generates fully rendered images, ready for display in an OMERO client application.

5.3. 5-Dimensional images

OMERO allows handling of up to 5-dimensional images. As well as the conventional x and y dimensions, you may store, view and manipulate z-sections, channels, and timepoints. The relationship of these multiple dimensions is illustrated in [Figure 5.3-1](#)




Figure 5.3-1 : Multiple dimensional images

5.4. The OMERO Data Model and Hierarchies

All information in OMERO revolves around a data structure called the object hierarchy. An understanding of this is core to efficient and effective use of OMERO. This hierarchy defines three kinds of objects:

1. Projects
2. Datasets
3. Images

and an organisational structure for grouping these objects together. This structure is shown in [Figure 4.4-1](#)




Figure 5.4-1 : OMERO Object hierarchy

At the top of the object hierarchy is the **project**. Projects represent a large, long-term investigation, usually by either a single OMERO user or a small collection of users in the same research group.

Each project contains a number of **datasets**. Projects and datasets form a many-to-many relationship; a project can contain more than one dataset, and each dataset can belong to more than one project. Most analysis routines are performed at the dataset level. This provides both a convenient batch processing capability, and the ability to calculate aggregate information about the contents of a dataset.

Each dataset contains a number of **images**. Like projects, images form a many-to-many relationship with datasets. Images in OMERO are inherently multi-dimensional - they consist of pixels across the usual three spatial dimensions, and can include multiple colour channels and time series.

